

MTN Products



AquaCafé[®]r (K-Cup) Installation & Operations Manual



Reliably Serving A Thirsty World

Table of Contents

SPECIFICATIONS.....	1
TOUCH PADS INSTRUCTIONS.....	3
SET-UP INSTRUCTIONS.....	4
BOTTLE INSTRUCTIONS.....	5
INITIAL COLD & HOT RESERVOIR FILLS.....	6
AQUACAFÉ® R DRIP TRAY IS ADJUSTABLE.....	7
BREWING INSTRUCTIONS.....	8

Specifications

H/W/D

Height:	43.5"
Width:	14.1"
Depth:	17"

Weights

Net Weight:	37.5 lbs.
Gross Weight:	43.5 lbs.

Electrical

Voltage:	115V AC 60Hz
Current:	12A
Wattage:	1200W

Cooling and Heating Capacities

Cooling: 20, 5 oz. Cups at 50° F

Cold Thermostat Set Point: 41° F - 50° F
OFF: 45° F
ON: 50° F

Heating: 4, 6 oz. Cups at 165° F

Hot Thermostat/Thermistor: Cycle 172 - 190°F
OFF: 186.8° F
ON: 172.4° F

Specifications Continued

Hot Tank Size 1.0 Liter
 1200 Watt Internal Heating Element

Brewing Temperature: 194 - 200° F

Ounces:

Small: 6 oz.
Medium: 8 oz.
Large: 10 oz.

- This product should only be used with potable water.
- This product should only be used indoors in an area that will not freeze.
- This product must be installed on a level floor.
- This product should not be located next to a heat source and a 4" clearance should be maintained around the product for proper air circulation.
- Cooler should be installed within 6' of a power source. Receptacle must be three-pronged ground and extension cords should never be used.
- **THIS COOLER IS INTENDED TO BE PLUGGED INTO A RECEPTACLE OF THE GROUND FAULT CIRCUIT INTERRUPTING TYPE (GFCI).**
- Never transport cooler lying down since serious damage to the compress can occur.
- When removing the AquaHost™ from the carton, cut the bottom of the carton open and lift the carton off the cooler.

Touch Pads Instructions

1. When flashing, the bottle is empty.
2. Press to dispense water.
3. Press and hold for about 1 second to select hot water function.
4. Press to select cold-water function.
5. Select touch pad brightness. There are three settings (low, medium, high).
6. Press to select coffee feature. Press again to switch between cup sizes (6 oz., 8 oz., and 10 oz.)*
7. Display cup size.



* **Note:** Unit is designed to default to the 8 oz. cup position. Once a different cup size is selected, it becomes the default for the next brew.

Set-Up Instructions

Set cooler in desired location. Use the slot on the right hand side of the cooler to pull the door open.



Bottle Instructions

Peel the label off the 5-gallon bottle. Remove the bottle probe from inside the cooler.



Insert probe into bottle, slide the bottle into cooler and close the door.



Initial Cold & Hot Reservoir Fills

1. Connect the unit to 120V power outlet. After 10 seconds, the reservoir fill pump will actuate and the reservoirs will start to fill. It will take approximately 7 minutes for the reservoirs to fill.
2. Once the pump stops, place a cup under dispense nozzle and press button #2 (See page 4). The water will dispense from cold reservoir.
3. Press and hold button #3 for about 1 second (See page 4), and the dispense button will turn red.
4. Press the water dispense button and hold until water starts to dispense from the hot tank.
5. Once the hot tank has been primed, turn on the hot tank switch that is located on back of the cooler. Water will reach 186° F within 5 minutes.



AquaCafé® r Drip Tray Is Adjustable

Push the drip tray into the pocket above the metal clip on the machine to snap it together.



Pull the drip tray straight out to disconnect to dump the excess water, and to clean. Push it straight back in to snap it together. When the drip tray is in place, hold the drip tray from the side and squeeze the latch handle. This allows the drip tray to slide up and down for height adjustment. Once the desired location is set, just release your hand.



Brewing Instructions

1. Place coffee cup on cup holder.
2. Lift silver handle and place capsule into holder.
3. Pull down on silver handle until locked.
4. Brew will default to 8 oz. (Please refer to page 3, bottom note for default information). If less or more coffee is needed, press button 6 (See page 3) until correct cup size is selected.
5. If dispense light is solid red, press dispense button and coffee will brew. If dispense light is flashing, water has not reached optimum brewing temperature. Wait for the light indicator to turn solid red, and then press dispense button to brew.
6. Open handle, remove the removable capsule holder, discard empty capsule, and put the removable holder back in place for the next user.

MTN Products



Thank You For Choosing
AquaCafé® r (K-Cup)



Reliably Serving A Thirsty World